

Part# 8701 VW/Audi Software Kit Includes 5801

VW/Audi Software Application Table

Applicable: Systems that use Rapid Data Transfer through 2007

System	Year	Get & Reset Faults	Live Data	Code Module	Activations	Adaptation	Actual Values	Basic Settings	Module Version
Service Reminder		Reset Light							
Quick Test & Reset		●							
Engine Electronics**		●	●	●	●	●	●	●	●
Transmission		●	●	●	●	●	●	●	●
ABS		●	●	●	●	●	●	●	●
A/C Heating		●	●	●	●	●	●	●	●
Airbag		●	●	●	●	●	●	●	●
Instrument Cluster		●	●	●	●	●	●	●	●
AC Convenience Module		●	●	●	●	●	●	●	●
Level Control		●	●	●	●	●	●	●	●
Central Locking		●	●	●	●	●	●	●	●
Head Lamp Control		●	●	●	●	●	●	●	●
Anti-Theft (Immob)		●	●	●	●	●	●	●	●
Radio		●	●	●	●	●	●	●	●
Electronic Control		●	●	●	●	●	●	●	●
CAN Gateway		●	●	●	●	●	●	●	●
Driver's Seat		●	●	●	●	●	●	●	●
Interior Monitor		●	●	●	●	●	●	●	●
Tire Pressure Monitor		●	●	●	●	●	●	●	●
Driver's Door Electronics		●	●	●	●	●	●	●	●
Pass Door Electronics		●	●	●	●	●	●	●	●
Driver's Rear Door		●	●	●	●	●	●	●	●
Passengers Rear Door		●	●	●	●	●	●	●	●
Engine Electronics II	ALL	●	●	●	●	●	●	●	●
Clutch Control		●	●	●	●	●	●	●	●
Distance Control		●	●	●	●	●	●	●	●
Suspension		●	●	●	●	●	●	●	●
Steering System		●	●	●	●	●	●	●	●
Auxiliary Heater		●	●	●	●	●	●	●	●
Engine Electronics III		●	●	●	●	●	●	●	●
4-Wheel Drive		●	●	●	●	●	●	●	●
Brake Booster		●	●	●	●	●	●	●	●
Anti-Slip Control		●	●	●	●	●	●	●	●
Roof Control		●	●	●	●	●	●	●	●
Display/Control Head Rear		●	●	●	●	●	●	●	●
Left Light Control		●	●	●	●	●	●	●	●
Engine Electronics Other		●	●	●	●	●	●	●	●
Differential Locks		●	●	●	●	●	●	●	●
Navigation		●	●	●	●	●	●	●	●
Right Light Control		●	●	●	●	●	●	●	●
Diesel Pump		●	●	●	●	●	●	●	●
Brake Assist		●	●	●	●	●	●	●	●
Steering Assist		●	●	●	●	●	●	●	●
Sound System		●	●	●	●	●	●	●	●
Auto Light System		●	●	●	●	●	●	●	●
Electric Drive		●	●	●	●	●	●	●	●
Parking Brake		●	●	●	●	●	●	●	●
TV Tuner		●	●	●	●	●	●	●	●

VW/Audi Software Application Table Continued

System	Year	Get & Reset Faults	Live Data	Code Module	Activations	Adaptation	Actual Values	Basic Settings	Module Version
Auxiliary Fuel Tank		●	●	●	●	●	●	●	●
Towing Protection		●	●	●	●	●	●	●	●
Battery Control		●	●	●	●	●	●	●	●
Stabilizers		●	●	●	●	●	●	●	●
Seat Mirror Adjust		●	●	●	●	●	●	●	●
Voice Control		●	●	●	●	●	●	●	●
Wiper Electronics		●	●	●	●	●	●	●	●
Trailer		●	●	●	●	●	●	●	●
Battery Charger		●	●	●	●	●	●	●	●
Chassis Control		●	●	●	●	●	●	●	●
Emergency Call		●	●	●	●	●	●	●	●
Parking Aid		●	●	●	●	●	●	●	●
Telephone		●	●	●	●	●	●	●	●
Right Slide Door		●	●	●	●	●	●	●	●
Left Slide Door		●	●	●	●	●	●	●	●
Media Player, Position 1		●	●	●	●	●	●	●	●
Media Player, Position 2		●	●	●	●	●	●	●	●
Media Player, Position 3	ALL	●	●	●	●	●	●	●	●
Media Player, Position 4		●	●	●	●	●	●	●	●
Digital Radio		●	●	●	●	●	●	●	●
Vehicle Position Detection		●	●	●	●	●	●	●	●
Driver Identification		●	●	●	●	●	●	●	●
Satellite Tuner		●	●	●	●	●	●	●	●
Intercom		●	●	●	●	●	●	●	●
Digital TV		●	●	●	●	●	●	●	●
Special Function		●	●	●	●	●	●	●	●
Data Transfer		●	●	●	●	●	●	●	●
Control Head, Right Rear		●	●	●	●	●	●	●	●
Central Electronics II		●	●	●	●	●	●	●	●
Operations		●	●	●	●	●	●	●	●
Control Head, Left Rear		●	●	●	●	●	●	●	●
Information Electronics		●	●	●	●	●	●	●	●
Trunk Electronics		●	●	●	●	●	●	●	●
Control Head, Roof		●	●	●	●	●	●	●	●
Central Convenience II		●	●	●	●	●	●	●	●
Control Head, Dash		●	●	●	●	●	●	●	●

** Engine Electronics include Readiness Codes and Selectable Live Data

Note: Not all modules are found in one particular vehicle.

Definition of Function names:
Module Version - Identify the control module part number and coding version
Get/Reset Faults - Read and reset manufacturer diagnostic trouble codes
Live Data - Access live data
Activation - Selected components can be activated
Code Module - Code new control modules (most models through 2007, includes 5, 7 Digit, and Long Coding)
Adaptation - Read/reset service light parameters, view/change block learn values
Basic Settings - View and change control module default settings (Excluding 1.8T 01 and newer)
Individual Values - Read individual measuring values
Readiness Code - Check status of applicable emissions related systems
Remote Control Programming - Program radio frequency keys